



Instruction Sheet

WARNING

- 1. Prior to installation, read instruction sheet manual and data sheet.
- 2. Prior to installation, inspect product for defects.
- 3. Verify that the electrical supply wires comply with data sheet/charts A, B & C.
- 4. All electrical work and materials must comply with the National Electrical Code (NEC), the Occupational Safety and Health Act (OSHA), and all state and local codes.
- 5. Installation work and electrical wiring must be done by a qualified person (s) in accordance with all applicable codes and standards, including fire-rated construction codes and standards

How do I install H2 Homer Helpers?

Step 1 Mount H2 to framing member

Mount H2 to framing member using #10 Pan Head wood screws or equivalent to. For maximum support, use six 1-1/4" screws to the face holes provided, plus two 2-1/2" screws through the corner holes (not included with purchase), for all mounting figure 1C options (see figure 1A, 1B and figure 1C). Place H2 Homer Helpers with max spacing of 4-1/2' per NEC.

figure 1A



figure 1B



Step 2 Route Supply Wires

Easily run your wire through 1-1/4" hole's provided.