

# Load Centers









## Load Center Accessories

### Load centers and meter combos

Touchsafe barriers are required for any single main service entrance application for a panel covered under UL 67. Line Terminal Barriers will be included in Main Breaker Load Centers and Single Main Meter Combos manufactured after January 1, 2017.

Single phase and 3-phase main breaker kits will include a barrier. Field installable kits are being created for replacements if needed and line terminal barriers are being added to hold down kits that can be used in back-fed applications. The barriers are designed to have minimal interference during load center installation, and can be removed and reattached as necessary.



	Catalog number	Description
	<b>ECLTB1</b>	For EQ Main Breakers/MBK kits 100A-125A
	<b>ECLTB2</b>	For EQ Main Breakers/MBK kits 150A-225A
	<b>ECLTB3</b>	For QN / QNR type breakers
	<b>ECLTB4</b>	For QR 3 phase breakers
	<b>ECMBR1<sup>①</sup></b>	For 2 Pole QP / MP-T type breakers for EQIII (extruded basepan) and Line 5 Load Centers
	<b>ECMBR2<sup>①</sup></b>	For 2 Pole QP / MP-T type breakers to be used with Ultimate LCs (now ES / PL), Murray or Rock Solid
	<b>ECMBR3</b>	For 3 Pole QP / MP-T type breakers to be used with PL, ES 3 phase load centers
	<b>ECLX387HD</b>	For 2 Pole MP-T type breakers in legacy Murray load centers

① Barrier fits with 2-pole QP 70A and above and all amperages of QPH and HQP.